



INSTALLATION INSTRUCTIONS

'94-'98 FORD MUSTANG COBRA STYLE FRONT BUMPER COVER

REVISED
01-21-02

PRODUCTS/MATERIALS INCLUDED:

QTY	PART #	DESCRIPTION
1	890114	COBRA STYLE FRONT BUMPER COVER

TOOLS REQUIRED:

1/8" DRILL BIT
UNIBIT
DRILL MOTOR
PHILLIPS SCREWDRIVER OR SCREWGUN
CENTER PUNCH

COBRA STYLE FRONT BUMPER COVER REPLACEMENT INSTALLATION PROCEDURE

NOTE : SAVE ALL THE FACTORY HARDWARE FOR REINSTALLATION OF THE WINGS WEST FRONT BUMPER.

OPEN THE HOOD AND REMOVE THE (2) FACTORY CLIPS THAT ARE LOCATED ON THE TOP OF THE BUMPER.

REMOVE THE (2) SCREWS IN EACH WHEEL WELL, AND THE (2) SCREWS WHERE THE BUMPER MEETS THE FENDER.

REMOVE THE (3) CLIPS AT THE BOTTOM OF THE FACTORY BUMPER, ALSO THERE ARE (2) URETHANE TABS THAT HOLD THE FACTORY BUMPER ON, THEY ARE LOCATED UNDER EACH HEAD LIGHT ON THE INSIDE OF THE BUMPER REACH IN AND PRY THE TABS LOOSE.

PULL THE FACTORY BUMPER OFF THE CAR AND DISCARD THE STYROFOAM ABSORBER.

REMOVE THE FACTORY FOG LIGHTS IF EQUIPPED.

NOTE THE LOCATION OF THE HOLES ON THE FACTORY BUMPER, USING THEM AS A TEMPLATE DRILL HOLES IN THE NEW WINGS WEST BUMPER IN THE SAME LOCATION. *NOTE: YOU MAY NEED TO FILE HOLES TO ASSURE A GOOD FIT.*

TEST FIT THE BUMPER ON THE CAR. SECURE THE WING WEST BUMPER WITH ALL THE FACTORY HARDWARE.

